



Features

HIGH CURRENT CARRY AND HIGH VOLTAGE

Inert gas filled arc chamber suitable for high voltage switching

COMPACT STRUCTURE, LOW NOISE

Small, low-profile design with low noise while carrying or switching loads

COIL ECONOMIZER

Economized coil for low power consumption

SAFE FOR EXPLOSIVE ENVIRONMENTS

No arc leakage due to a hermetically sealed design

HIGH RELIABILITY DESIGN

Hermetic sealing creates a stable environment for high voltage switching

VARIOUS APPLICATIONS

Pre-charge contactor, battery disconnect, EV charging, energy storage systems, photovoltaics, power control, circuit protection and much more

Sealing Type: Epoxy/Resin




Certification Information

- 1. Meet RoHS (2011/65/EU)
- 2. UL Approved







OPERATE / RELEASE TIME			
Operate Time	40ms, Max. @20°C		
Release Time	15ms, Max. @20°C		

ENVIRONMENTAL DATA					
Shock	Functional	196m/s² Sine half-wave pulse			
SHOCK	Destructive	490m/s² Sine half-wave pulse			
Operating	Temperature	-40 to +85°C			
Humidity		5% to 85%RH			
Weight		1.32 Lb. (600g)			

EXPECTED LIFE				
Electrical Endurance	400A@450VDC, 3000 Cycles			
Mechanical Life	200,000 Cycles			

Max. 50mV/100A)

COIL DATA					
Nominal Voltage	12-24VDC	24VDC			
Max. Voltage (20°C)	36VDC	32VDC			
Pick-up Voltage (20°C)	8-9VDC	18VDC			
Drop-out Voltage (20°C)	5-7VDC	11VDC			
Max. Inrush Current (20°C)	4A	0.55A			
Avg. Holding Current (20°C)	0.29A@12VDC 0.15A@24VDC 0.09A@36VDC	0.13A@24VDC			

Current	Carry	Curve	(250m ²)
---------	-------	-------	----------------------


Drop (initial)

								+]
	7200							+	\dashv	+
	=							\perp		
										1
•										
Time (Sec)							3			
Time										
	300			\perp						
	210			\downarrow				+		
	30							-		
			40	00 5	urrent	100 (A)	00		200	0

AUX. CONTACT				
Aux. Contact Arrangement	1 Form A			
Aux. Contact Current Max.	3A@24VDC/3A@125VAC			
Aux. Contact Current Min.	100mA@8V			

Rev F - 11-Dec-2023 Page |2









Electrical Life

Estimated Make and Break Resistive Load Ratings





Outline Dimensions: inches (mm)




- Matching fastener components: 2 x M8 stainless steel flat washer 2 x M8 stainless steel spring washer 2 x M8 x1.25 stainless steel nut









Part Number	Wire Diameter
AES400-CA	22AWG
AES400-MA	22AWG

Note:

The wire length is 15.4 ± 0.4 (390 ± 10)





Application Notes

- To prevent loosening, split washers should be used whenever the contactor is installed. All terminals or conductors must be in direct contact with the contactor's main terminals. Please control the tightening torque of each part within the specified range in the table below. If the torque exceeds the recommended range, it may cause damage to the sealed cavity and thread damage.
 - Contact torque: (M8) 80-100 lb. in. (8.8 11 N.m)
 - Mounting torque: 20.4 lb. in. (2.3 N.m) Max.
- 2. Products with polarity marked on the load end must be used correctly according to the product label. When the load connection polarity is reversed, the electrical characteristics in this data sheet cannot be guaranteed.
- 3. Products with a coil economizer are already equipped with back EMF circuits, so there is no need to use surge protectors.
- 4. Avoid installing the contactor in a strong magnetic field environment (near transformers or magnets) and avoid placing the contactor near objects with heat radiation.
- 5. When continuous current is applied to the contacts of the relay, and the coil is turned on immediately after the power is cut off. At this time, as the temperature of the coil increases, the resistance of the coil will also increase, which will increase the pull-in voltage of the product, which may result in exceeding the rated pull-in voltage. In this case, the following measures should be taken to reduce the load current; limit the continuous power-on time or use a coil voltage higher than the rated pull-in voltage.
- 6. When the voltage applied to the coil exceeds the maximum allowable applied voltage, the coil temperature may rise and lead to coil damage and inter-layer short circuit.
- 7. The rated values in the contact parameters are values for resistive load. When using an inductive load with L/R>1ms, please connect a surge current protection device to the inductive load in parallel. If no measures are taken, the electrical life may be reduced and the continuity may be poor. Please consider sufficient margin space in the design.
- 8. Coil drive power must be greater than coil power or it will reduce performance capability.
- Please do not allow debris and oil to adhere to the main terminals; Make sure that the main terminals are in reliable contact with the load conductor, otherwise the temperature rise of the terminal / conductor connection may be too high due to the excessive contact resistance.
- 10. The load conductor must have the corresponding current load capacity and heat dissipation capacity (it is recommended to use a copper bar with min 250mm²), to prevent overheating and affecting the life of the contactor.
- 11. It is impossible to determine the performance parameters of contactors in each specific application, therefore, customers should choose the products according to their own conditions of use. If in doubt, contact Altran. The customer will be responsible for validating that the products meet their application.
- 12. Do not use if dropped.
- 13. Altran reserves the right to make product changes as needed. Customers should reconfirm the contents of the specification or ask for us to supply a new specification if necessary.

Page |4 Rev F - 11-Dec-2023